


# QUANTUM AUTOMATIC SECUREMENT

Quantum Automatic Securement Stations are available in a significant amount of Sun Tran buses and can provide better efficiency in boarding and securing mobility devices. These are the primary steps to using the system. Scan the QR code below to watch a video with more detail on the process.




**Pre-trip the system before you begin service**



**After you deploy the ramp, power on the Quantum**




**The rider will center their mobility device in the bay and turn off the power**



**The rider will press the green secure button. Or, you can press secure on the driver panel.**



**Once the Quantum arms have secured the device, press the secure button on the driver panel to complete the process.**



**Offer the lap/shoulder belt.**



**Power off Quantum when not in use**

**For help with any issues, call dispatch and request maintenance**



**Scan to view the Quantum video**

